



**Condensed Installation Recommendations**

1. Install Base Panel over membrane; attach with approved fasteners on each panel end and at 18" O.C. max.
2. Install heater cables into slot.
3. Inspect heater cables and test at junction box; correct if necessary.
4. Install Panel Cover, attach with approved fasteners 24" O.C. Inspect heater cables and test at junction box; correct if necessary.
5. Counterflash Panel cover and fasteners by applying 12" continuous membrane; ensure membrane is not exposed when roofing is installed.
6. Install roofing per roofing manufacturer.
7. Consult Summit Ice Melt Systems for special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.

 <p><b>summit</b> ICE MELT SYSTEMS</p>	<p><b>Summit Ice Melt Systems, Inc.</b></p> <p><i>Thermodynamics analyzed. Applied.™</i></p> <p>Patent pending</p> <p>2911 Lake Forest Road - P.O. Box 6928 Tahoe City, CA 96145-6928 Ph: 530-583-8888 - Fax: 530-583-7777 summiticemelt.com</p>		<p>Scale</p> <p>Do Not Scale</p>	<p>Date</p> <p>2-21-13</p>	<p>Title</p> <p>LT™ New Metal Roofing</p>
	<p>Dimensions shown are for reference only.</p>			<p>Drawing Number</p> <p>230</p>	