



Installation Recommendations

1. Apply single ply roofing over roof deck per roofing manufacturer.
2. Install LowSlope™ Base Panel; attach 1-1/2" up from ex. fascia corner with approved fasteners at 16" O.C.
3. Install Heater Cables. Inspect and test, make corrections if necessary.
4. Install LowSlope Panel Cover by pressing tightly against Base Panel to ensure optimal heat transfer; attach with approved fasteners 16" O.C.
5. Complete single ply roofing system over Panel Cover and fasteners per roofing manufacturer.
6. Consult Summit Ice Melt Systems for special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.



Summit Ice Melt Systems, Inc.
Thermodynamics analyzed. Applied.™

2911 Lake Forest Road - P.O. Box 6928
 Tahoe City, CA 96145-6928
 Ph: 530-583-8888 - Fax: 530-583-7777

Scale Do Not Scale	Date 10-14-13	Title LowSlope New Single Ply
Dimensions shown are for reference only.		Drawing Number 450