


Condensed Installation Recommendations

1. Install PRO Base Panel over first course of existing shingles; attach Base Panel with approved #14 lag screws at max. 24" O.C., provide 1/2" spacing.
2. Install Heater Cables into upper and lower slots. Do not use Auxiliary/ middle slot unless specified in System Layout.
3. Inspect heater cables and test at junction box; correct if necessary.
4. Install Cover Panel by tucking under third course of shingles, provide 1/2" spacing. Attach with approved fasteners at 16" O.C. max. Inspect heater cables and test at junction box; correct if necessary.
5. Seal Cover Panel with sealant across top edge to counterflash.
6. Consult Summit Ice Melt Systems for special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.

 <p>Summit Ice Melt Systems, Inc. <i>Thermodynamics analyzed. Applied.™</i> Protected under U.S. Patents #8,946,601, #10,072,422 and other patents pending. 2911 Lake Forest Rd., P.O. Box 6928, Tahoe City, CA 96145 530/583-8888 summiticemelt.com info@summiticemelt.com</p>	Scale Do Not Scale	Revision Date 4-15-2019	Title PRO® Existing Composition Shingle Roofing
	Dimensions shown are for reference only.		Drawing Number 120