


- Condensed Installation Recommendations**
1. Install Radiant Edge Base Panel over first course of existing shingles; attach Base Panel with approved #14 lag screws at max. 24" O.C.
 2. Install Heater Cables into upper and lower slots. Do not use Auxiliary/ middle slot unless specified in System Layout.
 3. Inspect heater cables and test at junction box; correct if necessary.
 4. Install Panel Cover by tucking under third course of shingles. Attach with approved fasteners at 24" O.C. max. Inspect heater cables and test at junction box; correct if necessary.
 5. Seal Panel Cover with sealant across top edge to counterflash.
 6. Consult Summit Ice Melt Systems for special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.

 <p>summit ICE MELT SYSTEMS</p>	<p align="center">Summit Ice Melt Systems, Inc. <i>Thermodynamics analyzed. Applied.™</i></p> <p align="center">2911 Lake Forest Road - P.O. Box 6928 Tahoe City, CA 96145-6928 Ph: 530-583-8888 - Fax: 530-583-7777</p>	<p>Scale Do Not Scale</p>	<p>Revision Date 8-22-13</p>	<p>Title Radiant Edge PRO™ Existing Composition Shingle Roofing</p>
		<p>Dimensions shown are for reference only.</p>		<p>Drawing Number 120</p>