


**Condensed Installation Recommendations**

1. Install Base Panels over existing membrane (provide 1/2" spacing), attach with approved #14 lag screws at max. 24" O.C.
2. Install heater cables into upper and lower slots. Do not use Auxiliary/ middle slot unless specified in System Layout.
3. Inspect heater cables and test at junction box; correct if necessary.
4. Install Cover Panels (provide 1/2" spacing). Attach with approved fasteners at 24" O.C. max. Inspect heater cables and test at junction box; correct if necessary. Install Splice Covers.
5. Counterflash Cover Panels and fasteners by applying 12" continuous membrane; ensure membrane is not exposed when roofing is installed.
6. Install roofing per roofing manufacturer.
7. Consult Summit Ice Melt Systems for special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.

 <p><b>Summit Ice Melt Systems, Inc.</b>  <i>Thermodynamics analyzed. Applied.™</i></p> <p>Protected under U.S. Patents #8,946,601, #10,072,422 and other patents pending.</p> <p>2911 Lake Forest Rd., P.O. Box 6928, Tahoe City, CA 96145 530/583-8888  summiticemelt.com info@summiticemelt.com</p>	Scale Do Not Scale	Revision Date 4-17-2019	Title <b>PRO®</b> Under New Metal Roofing
	Dimensions shown are for reference only.		Drawing Number 130