



Condensed Installation Recommendations

1. Cut existing metal roofing panel approximately 5" up from fascia as required. Be careful not to damage existing membrane. Install Base Panel over existing membrane; attach with approved fasteners on each panel end and at 18" O.C. max.
2. Install Heater Cables.
3. Inspect heater cables and test at junction box; correct if necessary.
4. Install Panel Cover under existing metal roofing panels. Attach with approved fasteners at 24" O.C. max. Inspect heater cables and test at junction box; correct if necessary.
5. Install sealants and/or closures under roofing panel per metal roofing manufacturer.
6. Secure metal roofing with waterproof fasteners per metal roofing manufacturer.
7. Consult Summit Ice Melt Systems for special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.

 <p>summit ICE MELT SYSTEMS</p>	<p>Summit Ice Melt Systems, Inc. <i>Thermodynamics analyzed. Applied.™</i> Patent pending</p> <p>2911 Lake Forest Road - P.O. Box 6928 Tahoe City, CA 96145-6928 Ph: 530-583-8888 - Fax: 530-583-7777 summiticemelt.com</p>	Scale Do Not Scale	Date 2-21-13	Title LT™ Existing Metal Roofing
	Dimensions shown are for reference only.			Drawing Number 240