


Installation Recommendations

1. Insert HotSlot's top flange under 2nd course of shingles. Ensure access to Heater Slot for Heater Cable insertion before completing fastening. Gap panel ends 1/16".
2. Attach with approved, pre-painted waterproof screws max. 24" O.C. Penetrate roof sheathing minimum 1".
3. Insert Heater Cable into slot, press firmly in place.
4. Inspect and test heater cables; correct if necessary before proceeding. Connect to protected circuit.
5. For a more weatherproof assembly, Summit recommends applying sealant to underside of pre-drilled holes, along top edge and panel ends.
6. Consult Summit Ice Melt Systems for current information, special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.

All specifications subject to change without notice.



Summit Ice Melt Systems, Inc.
Thermodynamics analyzed. Applied.™

Patent-pending
 2911 Lake Forest Road - P.O. Box 6928
 Tahoe City, CA 96145-6928
 Ph: 530-583-8888 - Fax: 530-583-7777
 summiticemelt.com

Scale
 Do Not
 Scale

Date
 7-14-2013

Title
 HotSlot™ with
 existing composition
 shingle roofing

Dimensions shown are
 for reference only.

Drawing Number
 320