



Installation Recommendations

1. Verify with metal roofing manufacturer the suitability of HotSlot panel use with their product.
2. Insert HotSlot's top flange under existing metal roofing. Ensure access to Heater Slot for Heater Cable insertion before completing fastening. Gap panel ends 1/16".
3. Insert Heater Cable into slot, press firmly in place.
4. Attach per metal roofing manufacturer. Penetrate roof sheathing minimum 1". Hot Slot panel may require field pre-drilling.
5. Inspect and test heater cables; correct if necessary before proceeding. Connect to protected circuit.
6. Consult Summit Ice Melt Systems for current information, special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.

All specifications subject to change without notice.



Summit Ice Melt Systems, Inc.
Thermodynamics analyzed. Applied.™

Patent-pending
 2911 Lake Forest Road - P.O. Box 6928
 Tahoe City, CA 96145-6928
 Ph: 530-583-8888 - Fax: 530-583-7777
 summiticemelt.com

Scale
 Do Not
 Scale

Date
 4-19-2013

Title
 Radiant Edge HotSlot™
 Under Metal Roofing

Dimensions shown are
 for reference only.

Drawing Number
 340