


Installation Recommendations

1. Apply waterproof membrane over roof deck
2. Install LowSlope™ Base Panel over membrane; attach 1-1/2" up from ex. fascia corner with approved fasteners at 16" O.C.
3. Install Heater Cables. Inspect and test, make corrections if necessary.
4. Install LowSlope Panel Cover. Ensure full contact with Cover panel to extrusion for proper heat conductivity. Inadequate contact will result in poor performance. Attach with approved fasteners 16" O.C.
5. Counterflash Panel Cover and fasteners by continuing waterproof membrane or, at minimum, apply 12" continuous strip to counterflash and waterproof fasteners and Panel Cover.
6. Install metal roofing per metal roofing manufacturer.
5. Consult Summit Ice Melt Systems for special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.

 <p>summit ICE MELT SYSTEMS</p>	<p>Summit Ice Melt Systems, Inc. <i>Thermodynamics analyzed. Applied.™</i></p> <p>2911 Lake Forest Road - P.O. Box 6928 Tahoe City, CA 96145-6928 Ph: 530-583-8888 - Fax: 530-583-7777</p>		<p>Scale Do Not Scale</p>	<p>Date 5-7-2018</p>	<p>Title LowSlope™ New Metal Roofing</p>
	<p>Dimensions shown are for reference only.</p>			<p>Drawing Number 430</p>	