


Condensed Installation Recommendations

1. Verify insertion of Base Panel and Panel Cover under existing roofing; modify as necessary.
2. Install LowSlope Base Panel under metal roofing.
3. Install Heater Cables. Inspect heater cables and test at junction box; correct if necessary.
4. Install LowSlope Panel Cover, attach with waterproof screws max. 24" O.C. or as approved by metal roofing manufacturer.
5. Install sealants and/or closures under roofing panel per metal roofing manufacturer.
6. Consult Summit Ice Melt Systems for special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.

 <p>summit ICE MELT SYSTEMS</p>	<p>Summit Ice Melt Systems, Inc. <i>Thermodynamics analyzed. Applied.™</i></p> <p>2911 Lake Forest Road - P.O. Box 6928 Tahoe City, CA 96145-6928 Ph: 530-583-8888 - Fax: 530-583-7777</p>	Scale Do Not Scale	Date 10-14-13	Title LowSlope™ Existing Full Metal Roofing
		Dimensions shown are for reference only.		Drawing Number 440