



Installation Recommendations

1. Apply waterproof membrane over roof deck.
2. Install LowSlope™ Base Panel over membrane; attach 1-1/2" up from ex. fascia corner with approved fasteners at 12" O.C.
3. Install approved Heater Cables. Inspect, test, and correct if necessary.
4. Install LowSlope Panel Cover. Ensure full contact with Cover panel to extrusion for proper heat conductivity. Inadequate contact will result in poor performance. Attach with approved fasteners 12" O.C.
5. Apply 12" wide waterproof membrane strip across top edge of Cover Panel.
6. Install roofing per roofing manufacturer.
5. Consult Summit Ice Melt Systems for special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with GFCI Ground Fault protection.



Summit Ice Melt Systems, Inc.
Thermodynamics analyzed. Applied.™

2911 Lake Forest Road - P.O. Box 6928
 Tahoe City, CA 96145-6928
 Ph: 530-583-8888 - Fax: 530-583-7777

Scale
 Do Not
 Scale

Date
 2/12/2018

Title
 LowSlope New
 Roofing High
 Wind Area

Dimensions shown are
 for reference only.

Drawing Number
 460