

 Install Custom Cover Panels over PRO Base Panels and Hat/Valley Channels using approved fasteners at maximum 8" O.C. with 1/2" gap between adjacent Cover Panels.
 At gable ends, box-in Base Panels by field cutting/bending Cover Panels.

Inspect visible heater cables and perform second megger test at junction box; correct if necessary. Document readings.

- 7. On the underside of the Splice Cover, along each edge, apply a bead of sealant. Center the Splice Cover over the 1/2" gap between adjacent Cover Panels, press in place, and secure with approved fasteners.
- 8. Install counterflashing over Cover Panels, fasteners, and Splice Covers by applying 12" continuous membrane; ensure membrane is not exposed when roofing is installed.
- 9. Install shingles per manufacturer's instructions.
- Consult Summit Ice Melt Systems for special details and refer to Summit's Installation and Operation Guide. Per NEC, protect all circuits with 30mA Ground Fault protection.



Fascia







Summit Ice Melt Systems, Inc. Thermodynamics Analyzed. Applied.™

Protected under U.S. Patents #8,946,601, #9,982,438, #10,072,422, #10,604,937, and other patents pending. PRO*, LT*, LowSlope*, Valley Channel* and HotSlot* are registered trademarks of Summit Ice Melt Systems, Inc. "Thermodynamics analyzed. Applied", "Ultra-HECS", and "Apogee" are trademarks of Summit Ice Melt Systems, Inc.

summiticemelt.com
Phone: 530-583-8888



PRO® Extended 4-Pass 24" Stretchout with Valley/Hat Channel Assembly

 Scale
 Dwg #
 Date

 None
 111
 May 20, 2021